

Decoder-Adapter for Marklin Locos

Connection Type:	8 pin	21mtc *1	21mtc *2	Remarks
Model			Aux amplified	
Ae 8/14	8015	8015mtc		For use with Märklin light modules
Ae 8/14		8054mtc	8055mtc	For use with Lüssi light modules 8088
BR 03 / 43 / 50		8040	8041	For various tender steam locomotives
BR 17	8050	8050mtc	8051mtc	
BR 34		8048mtc		In development
BR 101	8052	8052mtc	8053mtc	
BR 128 / 12X	8042	8042mtc	8043mtc	
BR 152	8044	8044mtc	8045mtc	
Klasse C / BR 18.1	8071	8071mtc		With clip for pickup. For locos with long tender use item 8050 or 8051.
Klasse K	8075	8075mtc		Without clip for pickup.
Re 4/4 / Re 420	8016	8016mtc		For use with Märklin light modules, for locomotives w/o main beam light
Re 4/4 / Re 420	8076	8076mtc		For use with Märklin light modules, for locomotives with main beam light
Re 4/4 / Re 420		8046mtc	8047mtc	For use with Lüssi light modules 8084
Re 460 / Ae 6/6		8067 / 8068	8069	8067 for lamps, 8068 for LED light modules
Re 482 / BR 185 u.a.	8011	8011mtc		For various Märklin "Hobby" locos with Märklin light modules
Re 482 / BR 185 u.a.	8081	8081mtc		For various Märklin "Hobby" locos. Complete set with light modules
BR 232 u.a.	8081L	8081Lmtc		For various 6-axle Märklin "Hobby" locomotives. With light modules
Universal adapter			8079mtc	A customised version is available under 8079c
21mtc adapter		8096	8096A	Decoder adapter in the size of the direction switch
Adapter 21mtc to 8 pin		8097		For decoders with 8pin interface in locomotives with 21mtc connector

Notes:

*1 Use a decoder with amplified Aux outputs for adapters without amplified Aux connections

*2 Use a decoder with logic level on Aux outputs for adapters with amplified Aux connections